

A HIGHER LEVEL

INALTO

OF REFRIGERATION

USER MANUAL

INALTO

INALTO.HOUSE

# Single Zone Beverage Centre 142 Litres

---

MODEL CODE/S

IBC178.1

WWW.INALTO.HOUSE



E2447



A HIGHER LEVEL OF REFRIGERATION

# Welcome!

## Residentia Group Pty Ltd

—  
**Head Office**  
 165 Barkly Avenue, Burnley  
 Victoria Australia 3066

—  
**Postage**  
 PO Box 5177, Burnley  
 Victoria Australia 3121

—  
**ACN.**  
 600 546 656

—  
**Online**  
 residentia.group

Congratulations on purchasing your new appliance.  
 The InAlto brand is proudly distributed within Australia  
 by Residentia Group Pty Ltd.

Please refer to the warranty card at the rear of this manual for  
 information regarding your product's parts and labour warranty,  
 or visit us online at [www.residentia.group](http://www.residentia.group)

At Residentia Group, we are customer obsessed and our  
 Support Team are there to ensure you get the most out of your  
 appliance. Should you want to learn more about the various  
 features of your appliance, and importantly taking care of it  
 when cleaning, our Support Team are here to help. You can  
 use our online Support Centre at anytime by visiting:  
<http://support.residentia.group.com.au>

You can contact us via calling us on 1300 11 HELP (4357)  
 Or email us at: [support@residentiagroup.com.au](mailto:support@residentiagroup.com.au)

It is important that you read through the following use and care  
 manual thoroughly to familiarise yourself with the installation  
 and operation requirements of your appliance to ensure  
 optimum performance.

Again, thank you for choosing an InAlto appliance and we look  
 forward to being of service to you.

Kind Regards,  
 The Residentia Team

## Purchase Details

For future reference, please record the following information  
 which can be found on the rating plate and the date of  
 purchase which can be found on your sales invoice.

### STORE DETAILS

STORE NAME | \_\_\_\_\_

ADDRESS | \_\_\_\_\_

TELEPHONE | \_\_\_\_\_

PURCHASE DATE | \_\_\_\_\_

### PRODUCT DETAILS

MODEL NO. | \_\_\_\_\_

SERIAL NO.\* | \_\_\_\_\_



**A RESIDENTIA  
 GROUP INITIATIVE**



Attach your receipt to this page

## Contents

General Safety Instructions	4
Product Overview	6
Getting Started	8
Installation	9
Troubleshooting	12
Care and Maintenance	13
Technical Specifications	14
Warranty Information	16
Your Receipt	18
Purchase Details	19

## Customer Care

InAlto recommends the use of original spare parts. When contacting our customer service team, please ensure that you have the following information at hand (which can be found on your appliances' rating plate).

- Model Number
- Serial Number

# General Safety Instructions

## IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Read this manual thoroughly before first use, even if you are familiar with this type of product. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to. Make sure you understand all instructions and warnings.

Keep the manual in a safe place for future reference, along with the completed warranty card and purchase receipt. If you sell or transfer ownership of this product, pass on these instructions to the new owner.

Always follow basic safety precautions and accident prevention measures when using an electrical appliance, including the following:

**WARNING:** This is a Beverage Centre, this is not intended to be used to preserve or store fresh food or consumables.

A Beverage Centre is designed for the storage of cans/bottles at a set temperature that is particularly suitable for the drinks. The temperature maintained in this Beverage Centre is too high for safe storage of perishable foods.

### Electrical Safety

- **Voltage:** Before connecting and turning on the Beverage Centre, ensure the electrical voltage and circuit frequency correspond to that indicated on the appliance rating label.
- **Earthing:** This Beverage Centre should be properly earthed for your safety. The power cord of this Beverage Centre is equipped with a three-prong plug for use in standard wall outlets to minimise the possibility of electrical shock. Do not modify the cord and/or plug provided with the appliance. Improper use of the earthed plug can result in the risk of electric shock.
- **Connection:** This Beverage Centre requires a standard 220-240 V AC 50Hz electrical outlet. Do not overload the electrical circuit.

- **Power cord:** Do not kink or damage the power cord; do not leave it exposed or dangling. Secure it at the back of the appliance so no one steps on or places anything on the cord or against it. Keep the cord out of reach of children. When moving the appliance, make sure not to damage the power cord.
- **Auxiliary Items:** Do not use an inverter, adaptor or extension cord with this Beverage Centre. If the cord is too short, have a qualified electrician install an outlet near the appliance. Use of an extension cord and an inverter can negatively affect the performance of the unit.
- **Protect from moisture:** To protect against the risk of electric shock, do not immerse the unit, cord or plug in water or spray it with any other liquid. Do not connect or disconnect the electric plug when your hands are wet. Turn the power switch off before removing the plug from the socket.
- **WARNING: Disconnect!** To reduce the risk of fire, electric shock or personal injury, always unplug the appliance from the socket when not in use, when moving and before cleaning or servicing. Never unplug the unit by pulling the power cord. Always grip the plug firmly and pull straight out from the power point.
- **Electrical work:** Any electrical work required for the installation of this appliance should be carried out by a qualified electrician.

### Usage Conditions and Restrictions

- **Domestic use only:** This Beverage Centre is intended for indoor or outdoor household use only. It is not intended for commercial or industrial use.
- **Purpose:** Do not use this Beverage Centre for anything other than its intended purpose. Other uses are not recommended and may cause fire, electric shock or personal injury.
- **Attachments:** The use of attachments is not recommended by the appliance manufacturer and distributor as they may be hazardous.
- **Improper use:** Damage due to improper use, or repairs made by unqualified personnel will void your warranty. We assume no liability for any eventual damages caused by misuse of the product or noncompliance with these instructions.

7. You may not make a claim under this warranty unless the defect claimed is due to faulty or defective parts or workmanship. Residentia Group is not liable in the following situations (which are not exhaustive):
  - (a) the Appliance is damaged by:
    - (i) accident
    - (ii) misuse or abuse, including failure to properly maintain or service
    - (iii) normal wear and tear
    - (iv) power surges, electrical storm damage or incorrect power supply
    - (v) incomplete or improper installation
    - (vi) incorrect, improper or inappropriate operation
    - (vii) insect or vermin infestation
    - (viii) failure to comply with any additional instructions supplied with the Appliance;
  - (b) the Appliance is modified without authority from Residentia Group in writing;
  - (c) the Appliance's serial number or warranty seal has been removed or defaced;
  - (d) the Appliance was serviced or repaired by anyone other than Residentia Group, an authorised repairer or ASR.
8. This warranty, the contract to which it relates and the relationship between you and Residentia Group are governed by the law applicable where the Appliance was purchased.
9. To the extent permitted by law, Residentia Group excludes all warranties and liabilities (other than as contained in this document) including liability for any loss or damage whether direct or indirect arising from your purchase, use or non use of the Appliance.

10. For Appliances and services provided by Residentia Group in Australia, the Appliances come with a guarantee by Residentia Group that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Appliance repaired or replaced if the Appliance fails to be of acceptable quality and the failure does not amount to a major failure. The benefits to you given by this warranty are in addition to your other rights and remedies under a law in relation to the Appliances or services to which the warranty relates.
11. At all times during the Warranty Period, Residentia Group shall, at its discretion, determine whether repair, replacement or refund will apply if an Appliance has a valid warranty claim applicable to it.
12. To enquire about claiming under this warranty, please follow these steps:
  - (a) carefully check the operating instructions, user manual and the terms of this warranty;
  - (b) have the model and serial number of the Appliance available;
  - (c) have the proof of purchase (e.g. an invoice) available;
  - (d) telephone the numbers shown below.
13. You accept that if you make a warranty claim, Residentia Group and its ASR may exchange information in relation to you to enable Residentia Group to meet its obligations under this warranty.

### IMPORTANT

Before calling for service, please ensure that the steps in point 12 have been followed.

#### Telephone contact

- ▶ Service: Please call 1300 11 HELP (4357)

### The Australian Consumer Law requires the inclusion of the following statement with this warranty:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

# Warranty Information

## WARRANTY TERMS & CONDITIONS REFRIGERATION

This document sets out the terms and conditions of the product warranties for Residentia Group Appliances. It is an important document. Please keep it with your proof of purchase documents in a safe place for future reference should you require service for your Appliance.

### 1. IN THIS WARRANTY

- (a) 'acceptable quality' as referred to in clause 10 of this warranty has the same meaning referred to in the ACL;
  - (b) 'ACL' means Trade Practices Amendment (Australian Consumer Law) Act (No.2) 2010;
  - (c) 'Appliance' means any Residentia Group product purchased by you accompanied by this document;
  - (d) 'ASR' means Residentia Group authorised service representative;
  - (e) 'Residentia Group' means Residentia Group Pty Ltd of 165 Barkly Avenue Burnley VIC, ACN 600 546 656 in respect of Appliances purchased in Australia;
  - (f) 'major failure' as referred to in clause 10 of this warranty has the same meaning referred to in the ACL and includes a situation when an Appliance cannot be repaired or it is uneconomic for Residentia Group, at its discretion, to repair an Appliance during the Warranty Period;
  - (g) 'Warranty Period' means:
    - (i) where the Appliance is used for personal, domestic or household use (i.e. normal single family use) as set out in the instruction manual, the Appliance is warranted against manufacturing defects for 36 months, following the date of original purchase of the Appliance;
  - (h) 'you' means the purchaser of the Appliance not having purchased the Appliance for re-sale, and 'your' has a corresponding meaning.
2. This warranty only applies to Appliances purchased and used in Australia and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia.
  3. During the Warranty Period Residentia Group or its ASR will, at no extra charge if your Appliance is readily accessible for service, without special equipment and subject to these terms and conditions, repair or replace any parts which it considers to be defective. Residentia Group or its ASR may use remanufactured parts to repair your Appliance. You agree that any replaced Appliances or parts become the property of Residentia Group. This warranty does not apply to light globes, batteries, filters or similar perishable parts.
  4. Parts and Appliances not supplied by Residentia Group are not covered by this warranty.
  5. You will bear the cost of transportation, travel and delivery of the Appliance to and from Residentia Group or its ASR. If you reside outside of the service area, you will bear the cost of:
    - (a) travel of an authorised representative;
    - (b) transportation and delivery of the Appliance to and from Residentia Group or its ASR, in all instances, unless the Appliance is transported by Residentia Group or its ASR, the Appliance is transported at the owner's cost and risk while in transit to and from Residentia Group or its ASR.
  6. Proof of purchase is required before you can make a claim under this warranty.

- **WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **Usage restriction:** This Beverage Centre is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.
- **Children:** Supervise young children to ensure they do not play with the appliance. Never allow children to operate, play with or crawl inside the Beverage Centre.
- **WARNING:** Do not use electrical appliances inside the Beverage Centre, unless they are of the type recommended by the manufacturer.
- **Explosive or flammable substances:** Do not store explosive substances such as aerosol cans with a flammable propellant in this Beverage Centre. Do not store or use petrol or any other flammable vapours and liquids in the vicinity of this or any other appliance. Do not use such substances for cleaning the Beverage Centre. The fumes can create a fire hazard or an explosion.
- **Damage:** Do not use the Beverage Centre if the power cord, plug or the Beverage Centre itself is damaged. If the cord is damaged, contact the after sales support line and have the cord replaced by qualified personnel in order to avoid a hazard.
- **WARNING:** Do not damage the refrigerant circuit.
- **Do not modify:** Do not attempt to alter or modify this Beverage Centre in any way.
- **Repair:** Do not attempt to repair or replace any part of your Beverage Centre unless it is specifically recommended in this manual. All other servicing should be referred to a qualified technician. Contact the after sales support line for advice.
- **WARNING:** Keep ventilation openings, in the Beverage Centre enclosure or in-built structure, clear of obstruction.

This symbol alerts you to take care as this Beverage Centre contains a flammable refrigerant (isobutane) and insulation blowing gas (cyclopentane). Do not expose it to high heat, sparks and open flames.

The refrigerant isobutane (R600a) is contained within the refrigerant circuit of the appliance, a gas with a high level of environmental compatibility, which is nevertheless flammable. During transportation and installation of the Beverage Centre, ensure that none of the components of the refrigerant circuit become damaged.

**Never use a Beverage Centre with a damaged refrigerant circuit!** If the coolant circuit becomes damaged, avoid proximity to open fires and all types of heat sources. The room in which the unit is located should be ventilated for a few minutes.

The room for installing the appliance must be at least 1m<sup>3</sup> per 8g of refrigerant. The amount and type of refrigerant in the appliance can be found in the technical specifications on page 18 and on the appliance rating plate.

**It is hazardous for anyone other than an Authorised Service Person to service this appliance. In Queensland the authorized Service Person MUST hold a Gas Work Authorisation for hydrocarbon refrigerants, to carry out Servicing or repairs which involve the removal of covers.**


Note: If using the Beverage Centre outside in an alfresco area ensure that it is directly connected to an outdoor power point and please ensure it is not left in the weather or in direct sunlight. All electrical connections are to be made in a dry area and outdoor power points must be weatherproof and installed by a qualified electrician. The appliance must not be exposed to rain.



**CAUTION**  
RISK OF FIRE

# Product Overview

## 142L Single Zone Beverage Centre



### Key:

- |                        |                        |
|------------------------|------------------------|
| A. Cabinet             | D. Levelling Feet (x4) |
| B. Touch Control Panel | E. Glass Door          |
| C. Shelves             | F. Lower Door Hinge    |

### Specification and Technical Parameters

This product complies with AS/NZS 60335.1 and AS/NZS 60335.2.24 electrical safety, and with EN 55014-1:2006+A1:2009 A2:2011 for electromagnetic compatibility.

### Rating Label

See below. This will also be affixed to the unit.

### Responsible Disposal

- At the end of its working life, do not throw this appliance out with your household rubbish. Electrical and electronic products contain substances that can have a detrimental effect on the environment and human health if disposed of inappropriately.
- This refrigeration appliance contains flammable refrigerants and insulation blowing gases, which must be removed before disposal. Observe any local regulations regarding the disposal of electrical consumer goods and dispose of it appropriately for recycling and recovery of the refrigerant. Contact your local authorities for advice on recycling facilities in your area.
- Danger:** Risk of child entrapment! To avoid the possibility of child entrapment, take off the door and leave the shelves in place before discarding your Beverage Centre so that children cannot easily climb inside.

# INALT?

## Single Zone Beverage Centre 142 Litres

	MODEL	IBC178.1
	CLIMATE CLASS	T
	STORAGE VOLUME	142L
	PROTECTION CLASS	I
	VOLTAGE	220-240V/50Hz
	INPUT CURRENT	0.9A
	LAMPS POWER	1W
	REFRIGERANT	R600a/25g
	DIMENSIONS (HxWxD)	820x595x575mm
	FOAMING AGENT	Cyclopentane
SERIAL NO.		

Made in PRC



Residentia Group Pty Ltd  
T. 1300 11 4357  
E: support@residentiagroup.com.au


# Technical Specifications

<b>Product Dimensions (H, W, D):</b>	820mm, 595mm, 575mm
<b>Weight (Net / Gross):</b>	41kg / 45.5kg
<b>Temperature Range:</b>	0–22°C
<b>Other Features:</b>	Touch control LED display
	White LED interior light
	Triple glazed door
	Stainless Steel and Glass Finish

## Accessories included:



Handle × 1



Screws × 2



Spacers × 2

Full instructions on how to fix the handle can be found on Page 9 of this manual

# Getting Started

## Unpacking

- **Packaging materials:** This Beverage Centre has been packaged to protect it against transportation damage. Remove all packaging materials from around and inside the Beverage Centre and keep the original packaging carton and materials in a safe place. It will help prevent any damage if the product needs to be transported in the future, and you can use it to store the Beverage Centre when it is not in use. In the event the carton is to be disposed of, please recycle all packaging materials where possible.
- **Suffocation:** Plastic wrapping can be a suffocation hazard for babies and young children, so ensure all packaging materials are out of their reach and disposed of safely.
- **Power cord:** Unwind the power cord to its full length and inspect it for damage. Do not use the Beverage Centre if it or its cord have been damaged or are not working properly. In case of damage, contact our after sales support line for advice on examination, repair or return of the damaged product.
- **Read the manual:** Read this manual to familiarise yourself with the Beverage Centre. Pay particular attention to the safety instructions on the previous pages.
- **Clean:** To remove any dust from transit and storage, clean the interior and exterior surfaces of the Beverage Centre with lukewarm water and a soft cloth. Dry thoroughly.

# Care and Maintenance

## Looking after your appliance

### Cleaning your appliance

- Make sure you unplug the appliance before starting to clean it.
- Do not pour water directly over your appliance.
- You can wipe the inner and outer sides with a soft cloth.
- Remove parts individually and clean by hand with soapy water. Do not place in dishwashers.
- Never use flammable, explosive or corrosive material for cleaning your appliance
- Dust behind the cooler and on the ground shall be timely cleaned to improve the cooling effect and energy saving.
- The interior of the cooler should be cleaned regularly to avoid odor.
- Check the door gasket regularly to make sure there are no debris.
- Please turn off the power before cleaning, remove all shelves.
- Clean the door gasket with mild soap and water.
- Use a soft cloth or sponge to clean the inside of the cooler, with two tablespoons of baking soda and a quart of warm water. Then rinse with water and wipe clean, and open the door and dry it naturally before the power is turned on.
- Do not use soap, detergent, scrub powder, spray cleaner, etc., as these may cause odors in the interior of the cooler.
- Clean the bottle frame and shelves with a mild detergent and dry with a soft cloth.
- Wipe the outer surface of the cooler with a soft cloth dampened with soapy water, detergent, etc., and then wipe dry.
- Do not use hard brushes, steel wool, wire brushes, abrasives, or solvents like, alcohol or acetone, boiling water, acids or alkaline to clean this appliance, as it may damage or deform the surface or interior.
- Do not rinse with water so as not to affect the electrical insulation properties.

### Light bulb replacement

The internal light is a LED type. To replace the lamp, please speak to after sales service provider.

### Power Failure

If the power failure lasts for up to 24 hours, keep the door closed. This will allow the stored bottles to stay cold as long as possible. If it lasts longer than 24 hours, it is advised to empty the cooler compartment and temporarily store the bottles in a portable chiller.

### Short vacation

There is no need to disconnect the appliance from the mains if you will be away for two to three weeks.

### Long vacation

Remove all the wine if you are away for three weeks or more. Unplug the appliance and leave the doors open to provide air circulation to prevent odour and mould.

If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.



# Troubleshooting

PROBLEM	SOLUTION
THE DOORS DO NOT CLOSE PROPERLY	<ul style="list-style-type: none"> <li>-Ensure there are no obstructions preventing door closure.</li> <li>-Check the door compartments and shelves are correctly in place.</li> <li>-Check the door seal is not warped or torn.</li> <li>-Check the appliance is level.</li> </ul>
UNUSUAL NOISES	<ul style="list-style-type: none"> <li>-Check that the appliance is on a flat, level surface and is stable.</li> <li>-Check the spacing's around the appliance and ensure it is not touching other items.</li> <li>-Bubbling and gurgling sound: This noise is emitted as the coolant fluid flow through the pipes within the system. This is normal.</li> <li>-Contraction and expansion of the inside walls may cause popping and cracking noises.</li> </ul>
THE COOLER DOOR WILL NOT OPEN	<ul style="list-style-type: none"> <li>-If the door has just been opened, leave it for a few minutes to allow the air pressure to equalise before trying again.</li> </ul>
THE COMPRESSOR RUNS CONSTANTLY	<ul style="list-style-type: none"> <li>-The temperature is set too cold: select a lower (warmer) setting.</li> <li>-The door is open, or something is obstructing proper door closure.</li> <li>-The room temperature is hotter than usual.</li> </ul>
THE EXTERNAL FRIDGE SURFACE IS WARM	<ul style="list-style-type: none"> <li>-The exterior walls can be warmer than room temperature. This is normal while the compressor works to transfer heat from inside the bottle cabinet.</li> </ul>
SMELLS/ODOURS	<ul style="list-style-type: none"> <li>-Check all the drinks that are in the cooler are in date and correctly packaged. Please remove anything that may be spoiled and repack if necessary.</li> <li>-Check for spillages throughout the cooler. Spillages may cause odours if left unwashed. Wash accordingly to the manufacturers advise.</li> </ul>

# Installation

## Installation requirements

Before starting to use your beverage centre, you should pay attention to the following points:

- Operating voltage for your wine cooler is 220-240V at 50Hz.
- We do not take the responsibility of the damages that occur due to ungrounded usage.
- Do not place your appliance in direct sunlight.
- Your appliance should be at least 50 cm away from stoves, Gas ovens and heaters, and should be at least 5 cm away from electrical ovens.
- Your wine cooler should never be used outdoors or left out in the rain.
- When your wine cooler is placed next to a deep freezer, there should be at least 2 cm between them to prevent humidity on the outer surface.
- Do not place anything on your wine cooler, and install your wine cooler in a suitable place so that there is at least 10mm clearance at the top.
- Before using your wine cooler, wipe all parts with warm water, and then rinse and dry. Place all parts back in the appliance after cleaning.
- This appliance should be placed against a wall with a free distance of at least 30mm.
- The installation of this appliance is best carried out by 2 people.
- Dispose of all packaging carefully and responsibly.
- The appliance is designed for indoor use only and must be protected from rain, moisture and extreme temperature variations.
- This appliance is designed for household use. Do not use the appliance for industrial and commercial use, or any other purpose.
- The appliance MUST be positioned on a firm level base.

## Installation of your appliance


The appliance is designed for built-in, recessed or free standing installation. The minimum space required is : 615mm W x 605mm D X 830mm H ( refer to right photo)

IMPORTANT: Failure to follow the instructions regarding installation and ventilation may void the warranty supplied with your appliance.

## Installing the stainless steel handle


To install the handle, follow the instructions below:

1. Peel back door seal along the right hand side of door. You will find a screw hole at the top and lower of the door where you have peeled the seal back. (please refer to the diagram)
2. Take out the screws and spacers from bag at back of cabinet. Place the spacers onto screws and then put the screws in the hole where the handle is to be installed. Please make sure the spacer is correctly in place before you put the screws in the hole.
3. Align the handle with screws, tighten the screws using a screw driver until the handle is both flush and secured tightly against the door side. (DO NOT over-tighten as this may cause damage to the door surface)
4. After handle fixed well, put the door seal back to the door to cover the hole.



## Unpacking

- Please make sure that when unpacking your appliance that it is carried out in a safe manner. Ensure the packaging is disposed off in accordance to local regulation.
- Do not allow children to play with the packaging material, e.g. plastic bags and wrappings. **Danger of suffocation.**




### Levelling the feet

- The appliance must be installed level in order to work properly. If the unit is not level, the doors and magnetic seal alignments will not be covered properly.
- To level the unit, adjust one or both levelling feet at the base of the unit.

### Adjustable feet

This appliance comes with height adjustable feet which allows the appliance to be installed under bench and ensures the appliance is stable and level. Just screw the bottom feet anticlockwise to raise the height up to 880mm or clockwise to lower the height to 820mm. See below photos.



### Defrosting


The appliance is designed to defrost automatically every 4 hours. The defrost process will last for 20 minutes. During defrost, the compressor stops working and fan keeps on running for 20 minutes.

### Door alarm

The appliance is equipped with an alarm that will sound if the door is open for more than 60 seconds. Close the door or press any key once to switch off the alarm.

### Controls

It is recommended that you install appliance in a place where the ambient temperature is between 16°C - 32°C. If the ambient temperature is above or below recommended temperature, the performance of the unit may be affected. For example, placing your unit in extremely cold or hot conditions may cause interior temperatures to fluctuate. The operation temperature range may not be reached.



#### To switch the power on/off

- Press and hold the power button for 6 seconds to switch the wine cooler on.
- Press and hold the power button for 6 seconds again to switch the appliance off.

#### To change the temperature

- Continue to press the "+" or "-" buttons until the required temperature is shown on the display
- The preset temperature is 4°C/39°F.
- To change the temperature display from Fahrenheit to Celsius, or Celsius to Fahrenheit, press "+" and "-" button at the same time for 2 seconds. Tips, please see the "°C/°F" symbol on control panel.
- The display shows the current internal temperature when the appliance is on.

#### To use the internal light

- Press the light button to switch the light on or off.
- To turn the light ON when door opens, press the light button for 6 seconds, the display will show 'OP' which means door controls function is ON
- To turn the light function OFF, press the light button for 6 seconds, the display will show 'CL' which means the door control function is OFF.

#### To lock the whole panel

- Press power button and light button at the same time for one second, all the buttons on panel will be locked.
- Press power button and light button once again, all the buttons will be unlocked.

Tips, please see the "🔒" symbol on control panel.