


90cm Ceramic Cooktop




FEATURES

5 Cooking Zones inc. 2 Extendable Zones,
Slide Touch Controls, 9 Power Levels, 99 Minute Timer,
Durable Ceramic Glass, Child Lock

Congratulations on your new InAlto 90cm Ceramic Cooktop!

YOUR COOKTOP



Legend:

1. Max. 1800 W zone
2. Max. 1200 W zone
3. Max. 1100/2000 W zone
4. Max. 1000/2200 W zone
5. Max. 1200 W zone
6. Glass plate
7. Control panel

USING YOUR COOKTOP

To start cooking:

- Touch the "ON/OFF" control and all the indicators will show "-".
- Make sure the bottom of the pan and the surface of the cooking zone are clean and dry. Then place a suitable pan on the cooking zone that you wish to use.
- Touch the heating zone selection control for your desired zone. The indicator will flash.
- Adjust the temperature by using the font slider control. The options range from 0–9. You can modify this temperature at any time during cooking.

To end cooking:

- Turn the whole cooktop off by pressing the "ON/OFF" button.
- Alternatively you can select your desired zone and use the slider controls to change the temperature of this zone to zero "0". After a cooking zone is turned off, the corresponding indicator will show "H" until the zone has cooled to a safe temperature.

Note: For further operation instructions refer to pages 10–13 of your user manual.

DETAILS

Dimensions (W, D, H mm): 900 × 520 × 55
Built-in Dimensions (W, D mm): 875 × 495
Warranty: 3 Years (2 + 1 on registration)

SUPPORT

Telephone: 1300 11 4357
Email: support@residentiagroup.com.au